



Please read the operating instructions carefully before use and keep.

## Soccer table Profi Soccer Deluxe ST




## **Spare Part List**

opare rait List			
P1 = 2x	P2a = 2 x	P3 = 1 x	P4 = 4 x
Corner of	Harris Tolland		9
Side Panel LONG	Side Panel SHORT	Playfield	Legs
P5 = 8 x	P6 = 8x	P7 = 2x	P8 = 4x
		C. C	
ERGO Handles	Rod End Caps	Scorer	Apron Corners, chrom
P9 = 2 x	P10 = 3 x	H1 = 3x	H5= 6 +4 x
		Dame -	
Wooden Ball Collector	Playfield Support brace	Supprt brace, Rods	Head Nuts
P16 = 2x	P12 = 2 x	P11= 2 x	P13= 2 x
		OMBO!	8
Wooden Block, Ball Coll.	Chromed Leg Bar	Leg Bar Rods 716mm	Bottle Holder
P14 = 2x	P15 = 8x	A 1 = 2 x	A2 = 2x
			LDPE
Ball entry cup	Safety End Cap	Soccer Ball, standard	Tournament Ball

C1 = 2 x	C2 = 4 x	C3 = 2 x	C4 = 16 x
5er Solid Rod	3er Solid Rod	2er Solid Rod	Rubber Buffer
C5 = 32 x	C6 + C7 = 26 x	C11 = 4 x	C8 = 11 + 1 x
0			
Plastic Washer	Screws + Nut, Players	Goalie Stop ring	Player Away - white
C9 = 11 + 1 x	H2 = 32 x	H13 = 8 x	H3 = 4 x
	and a	a sugar	
Player Home - yellow	3/8 Flat washer	5/16 Flat washer	Leg Leveler Set
H6 = 28 x	H8 = 16 x	H10 = 4 x	H11 = 8 x
<u> </u>	On the state of		O Maria Maria
Wooden Screw 25 mm	Leg Screw 155 mm	Wooden Screw 25 mm	Cabinet Screw 80mm
H12 = 16 x	H14 = 4 x	H15 = 42 x	H16 = 6 x
			000
Leg Nut	Wooden Screw 25 mm Woodenblock	Wooden Screw 12 mm	Iron Angle - Ball Collector
A2 = 1 x			
Tool			

1) Set the Playfield P3 into the groove of Side panel P1 as FIGURE 1. Once you have the playfield set, place the Wood support brace P10 on the back of playfield and secure by Cabinet rods H1 locked at side panel by Nut H5.

Cabinet - Part 1




Attention – please make sure that in this step not all screws final fixed – only hold the parts




2) Attached the End panel P2 as show in FIGURE 2, use bolt H11 acrossing H13 to lock the side panel and the end panel, and fix playfield by screw H6. Then attach Apron miter P8 between the side panel and the end panel, locked by screw H15.

Note: Be sure that the Side panel and the End panel are square during this step.



**Attention** – please make sure that in this step now all screws final fixed by hand or within a screw driver or automatically screw driver with the lowest setting.


3) Put Wood ball collection P9 between the side panel and the end panel as FIGURE 3, using wooden blocks P16 and screw H14 to lock P9 on side panel, using Angle iron H16 and screw H15 to lock P9 on end panel and playfield.




Attention now please control that all screws are fixed.




4) Attach each Leg P4 into the table corner fixed by Bolt H8 acrossing washer H2 with Nut H12. Attach the Bars P12 between the Legs, using Rods P11 inserting bars and locked by Nut H5 outside legs. Locate Leg leveler H3 on the bottom of leg.






5) This step requires more than two adults to turn over the table carefully, not over the legs!!!!!

Then lock the scorer P7 on mid of end panel by screw H10. Use screw H15 to lock Ball entry cup on the top center of side panel. Fix Coffee back P13 on the end panel by screw H15. Put eight Handles P5 on the labeled side of rods, and align Player rods C2-C4 as FIGURE 5.



6) Lock Player C8, C9, Goalie rod stop ring C11 on player rods by screw C6 & Nut C7, then inserting two washer C5 on both sides of Rubber bushing C4 as FIGURE 6. Finally, put rod end caps P6 on another side of player rod.



Attention – again please final control that all screws are fixed with a hand screw drive or automatically screw driver with the lowest setting. To place the handles on the rods, please use a simple rubber hammer.

